

# CSCI 480 Computer Graphics

## Lecture 8

# Splines

Hermite Splines

Bezier Splines

Catmull-Rom Splines

Other Cubic Splines

[Angel Ch 12.4-12.12]

February 6, 2012


Jernej Barbic

University of Southern California

<http://www-bcf.usc.edu/~jbarbic/cs480-s12/>


# Roller coaster

- Next programming assignment involves creating a 3D roller coaster animation
- We must model the 3D curve describing the roller coaster, but how?



# Modeling Complex Shapes

- We want to build models of very complicated objects
- Complexity is achieved using simple pieces
  - polygons,
  - parametric curves and surfaces, or
  - implicit curves and surfaces
- This lecture: **parametric curves**



# What Do We Need From Curves in Computer Graphics?

- Local control of shape  
(so that easy to build and modify)
- Stability
- Smoothness and continuity
- Ability to evaluate derivatives
- Ease of rendering


# Curve Representations

- Explicit:  $y = f(x)$       $y = x^2$       $y = mx + b$ 
  - Must be a function (single-valued)
  - Big limitation—vertical lines?

- Parametric:  $(x,y) = (f(u),g(u))$ 
  - + Easy to specify, modify, control
  - Extra “hidden” variable  $u$ , the *parameter*  
 $(x, y) = (\cos u, \sin u)$


- Implicit:  $f(x,y) = 0$ 
  - +  $y$  can be a multiple valued function of  $x$
  - Hard to specify, modify, control

$$x^2 + y^2 - r^2 = 0$$




# Parameterization of a Curve

- *Parameterization* of a curve: how a change in  $u$  moves you along a given curve in xyz space.
- Parameterization is not unique. It can be slow, fast, with continuous / discontinuous speed, clockwise (CW) or CCW...



# Polynomial Interpolation

- An  $n$ -th degree polynomial fits a curve to  $n+1$  points
  - called Lagrange Interpolation
  - result is a curve that is too wiggly, change to any control point affects entire curve (non-local)
  - *this method is poor*
- We usually want the curve to be as smooth as possible
  - minimize the wiggles
  - high-degree polynomials are bad




source: Wikipedia

Lagrange interpolation,  
degree=15

# Splines: Piecewise Polynomials

- A spline is a *piecewise polynomial*:  
Curve is broken into consecutive segments, each of which is a low-degree polynomial interpolating (passing through) the control points
- *Cubic* piecewise polynomials are the most common:
  - They are the lowest order polynomials that
    1. interpolate two points and
    2. allow the gradient at each point to be defined ( $C^1$  continuity is possible).
  - Piecewise definition gives local control.
  - Higher or lower degrees are possible, of course.




a spline




# Piecewise Polynomials


- Spline: many polynomials pieced together
- Want to make sure they fit together nicely



Continuous in position




Continuous in position and tangent vector




Continuous in position, tangent, and curvature

# Splines

- Types of splines:
  - Hermite Splines
  - Bezier Splines
  - Catmull-Rom Splines
  - Natural Cubic Splines
  - B-Splines
  - NURBS



- Splines can be used to model both curves and surfaces



# Cubic Curves in 3D


- Cubic polynomial:
  - $p(u) = au^3 + bu^2 + cu + d = [u^3 \ u^2 \ u \ 1] [a \ b \ c \ d]^T$
  - $a, b, c, d$  are 3-vectors,  $u$  is a scalar
- Three cubic polynomials, one for each coordinate:
  - $x(u) = a_x u^3 + b_x u^2 + c_x u + d_x$
  - $y(u) = a_y u^3 + b_y u^2 + c_y u + d_y$
  - $z(u) = a_z u^3 + b_z u^2 + c_z u + d_z$

- In matrix notation:

$$\begin{bmatrix} x(u) & y(u) & z(u) \end{bmatrix} = \begin{bmatrix} u^3 & u^2 & u & 1 \end{bmatrix} \begin{bmatrix} a_x & a_y & a_z \\ b_x & b_y & b_z \\ c_x & c_y & c_z \\ d_x & d_y & d_z \end{bmatrix}$$

- Or simply:  $p = [u^3 \ u^2 \ u \ 1] A$

# Cubic Hermite Splines



We want a way to specify the end points and the slope at the end points!

# Deriving Hermite Splines

- Four constraints: value and slope (in 3-D, position and tangent vector) at beginning and end of interval  $[0,1]$  :

$$p(0) = p_1 = (x_1, y_1, z_1)$$

$$p(1) = p_2 = (x_2, y_2, z_2)$$

$$p'(0) = \bar{p}_1 = (\bar{x}_1, \bar{y}_1, \bar{z}_1)$$

$$p'(1) = \bar{p}_2 = (\bar{x}_2, \bar{y}_2, \bar{z}_2)$$

the user constraints

- Assume cubic form:  $p(u) = au^3 + bu^2 + cu + d$
- Four unknowns:  $a, b, c, d$

# Deriving Hermite Splines

- Assume cubic form:  $p(u) = au^3 + bu^2 + cu + d$

$$p_1 = p(0) = d$$

$$p_2 = p(1) = a + b + c + d$$

$$\bar{p}_1 = p'(0) = c$$

$$\bar{p}_2 = p'(1) = 3a + 2b + c$$

- Linear system: 12 equations for 12 unknowns  
(however, can be simplified to 4 equations for 4 unknowns)
- Unknowns:  $a, b, c, d$  (each of  $a, b, c, d$  is a 3-vector)

# Deriving Hermite Splines


$$d = p_1$$

$$a + b + c + d = p_2$$

$$c = \bar{p}_1$$

$$3a + 2b + c = \bar{p}_2$$

Rewrite this 12x12 system  
as a 4x4 system:



$$\begin{bmatrix} 0 & 0 & 0 & 1 \\ 1 & 1 & 1 & 1 \\ 0 & 0 & 1 & 0 \\ 3 & 2 & 1 & 0 \end{bmatrix} \begin{bmatrix} a_x & a_y & a_z \\ b_x & b_y & b_z \\ c_x & c_y & c_z \\ d_x & d_y & d_z \end{bmatrix} = \begin{bmatrix} x_1 & y_1 & z_1 \\ x_2 & y_2 & z_2 \\ \bar{x}_1 & \bar{y}_1 & \bar{z}_1 \\ \bar{x}_2 & \bar{y}_2 & \bar{z}_2 \end{bmatrix}$$

# The Cubic Hermite Spline Equation

- After inverting the 4x4 matrix, we obtain:

$$\begin{array}{cccc}
 \begin{matrix} \uparrow \\ [x \ y \ z] \end{matrix} & = & \begin{matrix} \uparrow \\ [u^3 \ u^2 \ u \ 1] \end{matrix} & \begin{bmatrix} 2 & -2 & 1 & 1 \\ -3 & 3 & -2 & -1 \\ 0 & 0 & 1 & 0 \\ 1 & 0 & 0 & 0 \end{bmatrix} & \begin{bmatrix} x_1 & y_1 & z_1 \\ x_2 & y_2 & z_2 \\ \bar{x}_1 & \bar{y}_1 & \bar{z}_1 \\ \bar{x}_2 & \bar{y}_2 & \bar{z}_2 \end{bmatrix}
 \end{array}$$

point on  
the spline

parameter  
vector

basis

control matrix

(what the user gets to pick)

- This form is typical for splines
  - basis matrix and meaning of control matrix change with the spline type




# Four Basis Functions for Hermite Splines

transpose

$$p(u) = \begin{bmatrix} 2u^3 - 3u^2 + 1 \\ -2u^3 + 3u^2 \\ u^3 - 2u^2 + u \\ u^3 - u^2 \end{bmatrix}^T \begin{bmatrix} p_1 \\ p_2 \\ \bar{p}_1 \\ \bar{p}_2 \end{bmatrix}$$

4 Basis Functions




Every cubic Hermite spline is a linear combination (blend) of these 4 functions.


# Piecing together Hermite Splines

It's easy to make a multi-segment Hermite spline:

- each segment is specified by a cubic Hermite curve
- just specify the position and tangent at each “joint” (called *knot*)
- the pieces fit together with matched positions and first derivatives
- gives C1 continuity




# Hermite Splines in Adobe Illustrator



# Bezier Splines

- Variant of the Hermite spline
- Instead of endpoints and tangents, four control points
  - points P1 and P4 are on the curve
  - points P2 and P3 are off the curve
  - $p(0) = P1$ ,  $p(1) = P4$ ,
  - $p'(0) = 3(P2 - P1)$ ,  $p'(1) = 3(P4 - P3)$
- Basis matrix is derived from the Hermite basis (or from scratch)
- Convex Hull property: curve contained within the convex hull of control points
- Scale factor “3” is chosen to make “velocity” approximately constant



# The Bezier Spline Matrix


$$\begin{bmatrix} x & y & z \end{bmatrix} = \begin{bmatrix} u^3 & u^2 & u & 1 \end{bmatrix} \begin{bmatrix} 2 & -2 & 1 & 1 \\ -3 & 3 & -2 & -1 \\ 0 & 0 & 1 & 0 \\ 1 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 0 & 1 \\ -3 & 3 & 0 & 0 \\ 0 & 0 & -3 & 3 \end{bmatrix} \begin{bmatrix} x_1 & y_1 & z_1 \\ x_2 & y_2 & z_2 \\ x_3 & y_3 & z_3 \\ x_4 & y_4 & z_4 \end{bmatrix}$$

Hermite basis
Bezier to Hermite
Bezier control matrix

$$= \begin{bmatrix} u^3 & u^2 & u & 1 \end{bmatrix} \begin{bmatrix} -1 & 3 & -3 & 1 \\ 3 & -6 & 3 & 0 \\ -3 & 3 & 0 & 0 \\ 1 & 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} x_1 & y_1 & z_1 \\ x_2 & y_2 & z_2 \\ x_3 & y_3 & z_3 \\ x_4 & y_4 & z_4 \end{bmatrix}$$

Bezier basis
Bezier control matrix

# Bezier Blending Functions




$$p(t) = \begin{bmatrix} (1-t)^3 \\ 3t(1-t)^2 \\ 3t^2(1-t) \\ t^3 \end{bmatrix}^T \begin{bmatrix} P_1 \\ P_2 \\ P_3 \\ P_4 \end{bmatrix}$$

Also known as the order 4, degree 3  
Bernstein polynomials

Nonnegative, sum to 1

The entire curve lies inside the  
polyhedron bounded by the  
control points

# DeCasteljau Construction




Efficient algorithm to evaluate Bezier splines.

Similar to Horner rule for polynomials.

Can be extended to interpolations of 3D rotations.

# Catmull-Rom Splines

- Roller-coaster (next programming assignment)
- With Hermite splines, the designer must arrange for consecutive tangents to be collinear, to get  $C^1$  continuity. Similar for Bezier. This gets tedious.
- Catmull-Rom: an interpolating cubic spline with *built-in  $C^1$  continuity*.
- Compared to Hermite/Bezier: fewer control points required, but less freedom.



Catmull-Rom spline



# Constructing the Catmull-Rom Spline

Suppose we are given  $n$  control points in 3-D:  $p_1, p_2, \dots, p_n$ .

For a Catmull-Rom spline, we set the tangent at  $p_i$  to  $s^*(p_{i+1} - p_{i-1})$  for  $i=2, \dots, n-1$ , for some  $s$  (often  $s=0.5$ )

$s$  is *tension parameter*: determines the magnitude (but not direction!) of the tangent vector at point  $p_i$

What about endpoint tangents? Use extra control points  $p_0, p_{n+1}$ .

Now we have positions and tangents at each knot. This is a Hermite specification. Now, just use Hermite formulas to derive the spline.

Note: curve between  $p_i$  and  $p_{i+1}$  is completely determined by  $p_{i-1}, p_i, p_{i+1}, p_{i+2}$ .

# Catmull-Rom Spline Matrix

$$[x \ y \ z] = [u^3 \ u^2 \ u \ 1] \begin{bmatrix} -s & 2-s & s-2 & s \\ 2s & s-3 & 3-2s & -s \\ -s & 0 & s & 0 \\ 0 & 1 & 0 & 0 \end{bmatrix} \begin{bmatrix} x_1 & y_1 & z_1 \\ x_2 & y_2 & z_2 \\ x_3 & y_3 & z_3 \\ x_4 & y_4 & z_4 \end{bmatrix}$$

basis

control matrix

- Derived in way similar to Hermite and Bezier
- Parameter  $s$  is typically set to  $s=1/2$ .

# Splines with More Continuity?

- So far, only  $C^1$  continuity.
- How could we get  $C^2$  continuity at control points?
- Possible answers:
  - Use higher degree polynomials  
degree 4 = quartic, degree 5 = quintic, ... but these get computationally expensive, and sometimes wiggly
  - Give up local control → natural cubic splines  
A change to any control point affects the entire curve
  - Give up interpolation → cubic B-splines  
Curve goes near, but not through, the control points

# Comparison of Basic Cubic Splines

Type	Local Control	Continuity	Interpolation
Hermite	YES	C1	YES
Bezier	YES	C1	YES
Catmull-Rom	YES	C1	YES
Natural	NO	C2	YES
B-Splines	YES	C2	NO

Summary:



Cannot get C2, interpolation and local control with cubics

# Natural Cubic Splines

- If you want 2nd derivatives at joints to match up, the resulting curves are called *natural cubic splines*
- It's a simple computation to solve for the cubics' coefficients. (See *Numerical Recipes in C* book for code.)
- Finding all the right weights is a *global* calculation (solve tridiagonal linear system)

# B-Splines

- Give up interpolation
  - the curve passes *near* the control points
  - best generated with interactive placement (because it's hard to guess where the curve will go)
- Curve obeys the convex hull property
- C2 continuity and local control are good compensation for loss of interpolation




# B-Spline Basis

- We always need 3 more control points than the number of spline segments

$$M_{Bs} = \frac{1}{6} \begin{bmatrix} -1 & 3 & -3 & 1 \\ 3 & -6 & 3 & 0 \\ -3 & 0 & 3 & 0 \\ 1 & 4 & 1 & 0 \end{bmatrix}$$

$$G_{Bsi} = \begin{bmatrix} P_{i-3} \\ P_{i-2} \\ P_{i-1} \\ P_i \end{bmatrix}$$



# Other Common Types of Splines

- Non-uniform Splines
- Non-Uniform Rational Cubic curves (NURBS)
- NURBS are very popular and used in many commercial packages



# How to Draw Spline Curves

- Basis matrix equation allows same code to draw any spline type
- Method 1: brute force
  - Calculate the coefficients
  - For each cubic segment, vary  $u$  from 0 to 1 (fixed step size)
  - Plug in  $u$  value, matrix multiply to compute position on curve
  - Draw line segment from last position to current position
- What's wrong with this approach?
  - Draws in even steps of  $u$
  - Even steps of  $u$  does not mean even steps of  $x$
  - Line length will vary over the curve
  - Want to bound line length
    - » too long: curve looks jagged
    - » too short: curve is slow to draw

# Drawing Splines, 2

- **Method 2: recursive subdivision** - vary step size to draw short lines

```
Subdivide(u0, u1, maxlinelength)
    umid = (u0 + u1) / 2
    x0 = F(u0)
    x1 = F(u1)
    if |x1 - x0| > maxlinelength
        Subdivide(u0, umid, maxlinelength)
        Subdivide(umid, u1, maxlinelength)
    else drawline(x0, x1)
```

- **Variant on Method 2** - subdivide based on curvature
  - replace condition in “if” statement with straightness criterion
  - draws fewer lines in flatter regions of the curve

# Summary

- Piecewise cubic is generally sufficient
- Define conditions on the curves and their continuity
- Most important:
  - basic curve properties  
(what are the conditions, controls, and properties for each spline type)
  - generic matrix formula for uniform cubic splines  $p(u) = u B G$
  - given a definition, derive a basis matrix  
(do not memorize the matrices themselves)